

Bowl-Tronics Enterprises Incorporated

Address: 1115 Sherwood Ave.
Elgin IL. 60120
Website: www.bowl-tronics.com
E-mail: rick@bowl-tronics.com

Phone: 847-741-4500

Transceiver Alignment Tester (TATPC & TATPC60HZ)

Transceiver Alignment Tester Theory

The transceiver alignment tester is designed to test if your transceiver is aligned properly and has an output level that is sufficient for reliable triggering. There are two LED's on the circuit board, one for the left lane the other for the right. You will know that your transceiver is aligned when both LED's are lit. If the LED's seem dim or not lit at all, you must align the transceiver. If the LED's never go completely on or not at all then the transceiver needs to be replaced.

Installation Instructions

Remember to remove power before performing any installation!!



First, start by removing the main PCM board from the triggering system and set it aside. Next, with the power off you will plug in the (TATPC) into the PC connector of the main PCM. Be sure to have the LED's facing you when you plug the (TATPC), view the diagram on the back page then restore power and test.

For repair visit: www.bowl-tronics.com/service

Fill out our service request form and ship to the address that is shown.

Notes:

Transceiver Alignment Tester Diagram



(Shown in a M-4 Triggering Unit)